





necessary.																							
Inspect the CV joints.		x		x		x		x		x		x		x		x		x		x		x	
Inspect the exhaust system.		x		x		x		x		x		x		x				x		x		x	
Adjust the parking brake on vehicles equipped with four wheel disc brakes.					x					x								x					x
Inspect the manual transmission fluid (If Equipped).			x			x			x			x			x			x			x		
Inspect the rear axle fluid.			x			x			x			x			x			x			x		
Change the manual transmission fluid (if equipped).								x															x
Change the rear axle fluid if using your vehicle for any of the following: police, taxi, fleet or frequent trailer towing.									x														x
Replace the engine air cleaner filter.					x					x												x	
Replace the air		x		x		x		x		x				x				x			x		

